

Your parts

Barrel Cannon set Wooden strip 2 x 3 x 300mm



Tools and equipment

PVA wood glue Knife Sandpaper Brushes Superglue Black and red paint

Razor saw Black pen

Ruler



Glue another wooden strip, beginning at the bow, 11mm below the previously placed one, as shown.



Continue to plank around the bow, keeping the wooden strip 2mm below the gun ports.





Continue placing wooden strips along the side of the hull. When you reach the stern, make sure that there is a gap of 12mm below the stern castle.






Begin placing a second set of wooden strips below the first.



Continue along the side of the hull, gluing a wooden strip directly below the one from Step c. Repeat these two rows on the port side of the hull.






When the glue is dry, smooth the surface of the wooden strips.






Check that the position and symmetry of the wooden strips

matches on both sides of the hull.



As shown in the photo, score two visible lines along the outer face of the rudder.








Glue lengths of planks to the rear of the rudder, as highlighted by the arrows.





Assemble the cannon set as with previous sets and, as before, mark the bands around the barrel.



 \mathbf{k}





Your parts

Cannon set Barrel Wooden strips 2 x 3 x 300mm



Tools and equipment

PVA wood glue Knife Sandpaper Brushes

Superglue Black and red paint

Ruler Black pen



Shape the end of a wooden strip to fit flush with the stern castle, with about half the width above it, as shown in the photograph.



Cut a piece of 2 x 3mm wooden strip to about 15mm in length. Glue the wooden strip from the last step to the side of the hull, using the 15mm length as a spacer to keep the height accurate.





As you get to the end of the wooden strip, move the spacer to the end to maintain an even height.





Continuing along the side of the hull, glue another wooden strip into place, again using the 15mm length to maintain the height.



Glue another wooden strip below the one from Step a. You may have to shape the end to get it flush with the stern castle.





Continue along the side of the hull, gluing another wooden strip in place, flush with the one above.





Smooth the surface of the two wooden strips so they are even.




Cut a length of 2 x 5mm wooden strip to fit at the bow, as shown.





Repeat these steps for the other side of the hull. Smooth the upright lengths at the bow so they are in line with the tops of the bulwarks.





Assemble the cannon set as with previous sets and, as before, mark the bands around the barrel.







Your parts

Cannon set Barrel Wooden strips 2 x 3 x 300mm



Tools and equipment

PVA wood glue Knife Sandpaper Brushes

Superglue Black and red paint

Tweezers Black pen



Cut a 2 x 3mm wooden strip to a length of 250mm and place it in the middle of the two strips, as shown.



Glue another strip, 300mm long, next to the one from the previous step. Overlap the joins, as indicated by the arrows.





Complete this row with another strip, again overlapping the joins.





Cut another 250mm length and place it on the wooden strips the next level up.



Continue aft with a 300mm length and then a shorter length at the stern.

Repeat Steps a-e for the other side of the hull.





Smooth the surface of the wooden strips on both sides of the hull.





Cut a length of 2 x 3mm wooden strip to fit at the point shown, and glue it into place.



Cut a length of 2 x 3mm wooden strip to fit 16mm below the bottom of the wooden strip from the previous step.






Using the remaining lengths of the 2 x 3mm wooden strips, cut four lengths, two to fit either side of the bowsprit hole and a further two to fit in line and above them.





Assemble the cannon set as with previous sets and, as before, mark the bands around the barrel.







Your parts

Cannon set Barrel Wooden strip 2 x 3 x 300mm Porthole decoration




Tools and equipment

PVA wood glue Knife Sandpaper Brushes Superglue Black and red paint Tweezers Black pen Pencil




Cut a 2 x 3mm wooden strip to 175mm in length, and glue it along the centre of the two uppermost strips.



Glue another strip along the two uppermost strips, next to the one in the previous step.





Complete this row with a final length of wooden strip.





Sand the surface of the wooden strips to smooth them.



Cut three pieces of 2 x 3mm wooden strip to fit vertically between the horizontal strips, aft of the fifth gun ports from the bow.



Hold a wooden strip over the three lengths from the last step and make a mark on each side of it on the horizontal strips, as shown.





Cut away the space between each pair of marks made in the last step on each of the strips.



Cut a length of strip to fit in the gaps made in the last step, from the top of the bulwarks to the top of the horizontal strip fitted on Page 233.



When the glue is dry, smooth the surface so that the wooden strips are flush at this point. Also, round the top of the strip.





Assemble the cannon set as with previous sets and, as before, mark the bands around the barrel.

