







**60** Make the bowsprit grating with parts **447** framed with the batten **448** and fit them in the space left between the upper coamings in the counter timbers. Make the bow boarding **449** to cover the gaps formed between the gratings. Glue the cleats **450**, tied off with the small blocks **451** threaded with the fine raw thread **88**. Fit three eyebolts **86**, one in the cleat and two in the stem to fit the medium brown thread **91** (see yellow arrows). Repeat this operation on the starboard side. With the help of the mast and rigging plans, fit the bowsprit **452**, lugs **453**, guides **454** and the cap **455**. Adjust the boom **456** and the swing boom **457** with the joining rings **458**. Mount the jack **459** tied off by the truck **460** and a small block **87**. Fit the dolphin boom **461**, fastened with the clamps **462**, and fit the deadeyes **463**, **464** with the medium brown thread **91** and the small blocks **451** and the block and tackle **281** with the raw cotton thread **465**.



**61** Glue the two strengtheners **466** in the bowsprit grating and make the bowsprit gammoning with the thick brown thread **467**. Fit the stay and counterstay on the mainsail (red arrows) and the stay and counterstay on the mainmast (blue arrows) with the thick brown thread **467**. These run from the bowsprit **452** and are joined to the deadeyes **463** that are linked via the stay lanyards made with the medium brown thread **91**. These stays and counterstays on the mainsail and foretop are to be tied on the upper part, wrapping the lower mainmast and the foresail on both masts and through their tops, tying them off with medium brown thread **91**. Make the bowsprit rigging with the thick brown thread **467** tied on the lower part to the eyebolts **86** previously fitted in the hull. On the upper part, fit the deadeyes **463** joined together by the rigging lanyards made with medium brown thread **91**.







**62** Refer to the rigging plan. Tie the bobstays around the bowsprit 452 with the thick brown thread 467. Join them together with the braiding made with the medium brown thread 91 and fasten them with staples 468 on the lower part to the hull. The staples are made from 2mm brass strapping in which two 1mm holes will need to be made to insert the pins 33. The large photo shows the shroud made with the medium brown thread 91, both for the interiors (blue arrows) and for the exteriors (red arrows). The small inset photos show where to tie up the shrouds in the eyebolts 86.